

.5 Hp/Straight Line/Front Exhaust Drill

Models:

53037 – 20,000 RPM


Air Motor and Machine Parts

! WARNING

Always operate, inspect and maintain this tool in accordance with the Safety Code for portable air tools (ANSI B186.1) and any other applicable safety codes and regulations. Please refer to Dynabrade's Warning/Safety Operating Instructions for more complete safety information.

Index Key

No.	Part #	Description
1	53032	1/4" Chuck (Incl. 53052 Chuck Key)
2	53175	Insulator Collar
3	04102	Lock Ring
4	04078	Felt Silencer
5	Air Control Ring	
	01124	15,000 RPM
	01125	18,000 RPM
	04084	20,000 RPM
	01126	24,000 RPM
6	04081	Rotor Nut
7	01007	Bearing
8	01121	Shim Pack (3/pkg.)
9	01008	Bearing Plate
10	50767	Pin (2)
11	01010	Rotor Spacer
12	01013	Cylinder
13	01120	Rotor
14	01011	Blade (4/pkg.)
15	01244	Bearing Plate
16	01015	Bearing
17	30443	Housing – 53037
18	57342	Throttle Lever
	01089	Safety Lock Lever (optional)
19	01017	Pin
20	95558	Retaining Ring
21	01477	Valve Stem
22	95730	O-Ring
23	01024	O-Ring
24	01247	Speed Regulator Assy.
25	01464	Seal
26	01472	Tip Valve
27	01468	Spring
28	53190	Block Plate
29	96065	O-Ring
30	01494	Inlet Adapter



Important Operating, Maintenance and Safety Instructions

Carefully read all instructions before operating or servicing any Dynabrade® Abrasive Power Tool.

Warning: Hand, wrist and arm injury may result from repetitive work motion and overexposure to vibration.

Important: All Dynabrade Rotary Vane air tools must be used with a Filter-Regulator-Lubricator to maintain all warranties.

Operating Instructions:

Warning: Eye, face, respiratory, sound and body protection must be worn while operating power tools. Failure to do so may result in serious injury or death. Follow safety procedures posted in workplace.

1. With power source disconnected from tool, securely fasten abrasive/accessory on tool.
2. Install air fitting into inlet bushing of tool. **Important:** Secure inlet bushing of tool with a wrench before attempting to install the air fitting to avoid damaging valve body housing.
3. Connect power source to tool. Be careful not to depress throttle lever in the process.
4. Check tool speed with tachometer. If tool is operating at a higher speed than the RPM marked on the tool or operating improperly, the tool should be serviced to correct the cause before use.

Maintenance Instructions:

1. Check tool speed regularly with a tachometer. If tool is operating at a higher speed than the RPM marked on the tool, the tool should be serviced to correct the cause before use.
2. Some silencers on air tools may clog with use. Clean and replace as required.
3. All Dynabrade Rotary Vane air motors should be lubricated. Dynabrade recommends one drop of air lube per minute for each 10 SCFM (example: if the tool specifications state 40 SCFM, set the drip rate of your filter-lubricator at 4 drops per minute). Dynabrade Air Lube (P/N 95842: 1pt. 473ml.) is recommended.
4. An Air Line Filter-Regulator-Lubricator must be used with this air tool to maintain all warranties. Dynabrade recommends the following: **11405** Air Line Filter-Regulator-Lubricator — Provides accurate air pressure regulation, two-stage filtration of water contaminants and micro-mist lubrication of pneumatic components. Operates 40 SCFM @ 100 PSIG has 3/8" NPT female ports.
5. Use only genuine Dynabrade replacement parts. To reorder replacement parts, specify the **Model #**, **Serial #**, and **RPM** of your machine.
6. A Motor Tune-Up Kit (P/N 95600) is available which includes assorted parts to help maintain motor in peak operating condition.
7. Mineral spirits are recommended when cleaning the tool and parts. Do not clean tool or parts with any solvents or oils containing acids, esters, ketones, chlorinated hydrocarbons or nitro carbons.

Safety Instructions:

Products offered by Dynabrade should not be converted or otherwise altered from original design without expressed written consent from Dynabrade, Inc.



- **Important:** User of tool is responsible for following accepted safety codes such as those published by the American National Standards Institute (ANSI).
- Operate machine for one minute before application to workpiece to determine if machine is working properly and safely before work begins.
- Always disconnect power supply before changing abrasive/accessory or making machine adjustments.
- Inspect abrasives/accessories for damage or defects prior to installation on tools.
- Please refer to Dynabrade's Warning/Safety Operating Instructions Tag (Reorder No. 95903) for more complete safety information.
- **Warning:** Hand, wrist and arm injury may result from repetitive work, motion and overexposure to vibration.

Notice

All Dynabrade motors use the highest quality parts and metals available and are machined to exacting tolerances. The failure of quality pneumatic motors can most often be traced to an unclean air supply or the lack of lubrication. Air pressure easily forces dirt or water contained in the air supply into motor bearings causing early failure. It often scores the cylinder walls and the rotor blades resulting in limited efficiency and power. Our warranty obligation is contingent upon proper use of our tools and cannot apply to equipment which has been subjected to misuse such as unclean air, wet air or a lack of lubrication during the use of this tool.

One Year Warranty

Following the reasonable assumption that any inherent defect which might prevail in a product will become apparent to the user within one year from the date of purchase, all equipment of our manufacture is warranted against defects in workmanship and materials under normal use and service. We shall repair or replace at our factory, any equipment or part thereof which shall, within one year after delivery to the original purchaser, indicate upon our examination to have been defective. Our obligation is contingent upon proper use of Dynabrade tools in accordance with factory recommendations, instructions and safety practices. It shall not apply to equipment which has been subject to misuse, negligence, accident or tampering in any way so as to affect its normal performance. Normally wearable parts such as bearings, sanding pads, rotor blades, etc., are not covered under this warranty.

Model Number	Motor HP (W)	Motor RPM	Air Inlet Thread	Sound Level	Air Flow Rate CFM/SCFM (LPM)	Air Pressure PSIG (Bars)	Spindle Thread	Weight Pound (kg)	Length Inch (mm)	Height Inch (mm)
53037	.5 (373)	20,000	1/4" NPT	87 dB(A)	4/27 (765)	90 (6.2)	3/8"-24 male	1.5 (.7)	7 (178)	1-3/4 (44)

Additional Specifications: Hose I.D. Size 3/8" (10 mm)

Disassembly/Assembly Instructions - .5 Hp Front Exhaust

Important: Manufacturer's warranty is void if tool is disassembled before warranty expires.

Motor Disassembly:

1. Disconnect tool from power source.
2. Secure air tool in soft jaw.
3. Remove drill chuck from rotor by inserting a 3/16" hex key through the chuck and into the end of the rotor shaft.
4. Use an adjustable pin wrench or **50971** Lock Ring Tool to remove **04102** Lock Ring by turning it counter-clockwise. Remove **04078** Felt Silencer and air control ring.
5. Pull motor assembly from housing and fasten a bearing separator around the end of the cylinder nearest the **01244** Rear Bearing Plate.
6. Place bearing separator on the table of a (#2) arbor press and push the rear rotor shaft out of the rear motor bearing. **Note:** A 3/16" diameter flat nose drive punch can be used as a press tool.
7. With cylinder and blades removed, secure the rotor body in a soft jaw vise and remove **04081** Rotor Nut, turning it counter-clockwise.
8. Press **01015** Rear Bearing out of **01244** Rear Bearing Plate with **96211** Bearing Removal Tool.

Motor Disassembly Complete.

Valve Disassembly:

1. Position motor housing in vise by holding on wrench flats, and with air inlet facing up.
2. Secure **01494** Inlet Adapter with a wrench and remove air fitting. Also, remove **01494** Inlet Adapter.
3. Remove **53190** Block Plate and **96065** O-Ring.
4. Remove **01468** Spring, **01472** Tip Valve and **01464** Seal.
5. Use a 2.5 mm drive punch to remove **01017** Pin and throttle lever from housing.
6. Remove **95558** Retaining Ring with external ring pliers and push **01247** Regulator from housing.

Valve Disassembly Complete.

Motor Assembly:

Important: Be sure parts are clean and in good repair before assembly.

1. Place rotor in soft jaw vise with a threaded spindle pointing up.
2. Slip **01010** Spacer onto rotor.
3. Place a .002" shim into front bearing plate as an initial spacing and slip **01007** Bearing into plate.
Note: **01121** Shim Pak contains .001" and .002" shims.
4. Install bearing/bearing plate assembly onto rotor.
5. Install **04081** Rotor Nut onto rotor (torque to 17 N•m/150 in. - lbs.).
6. Check clearance between rotor and bearing plate by using a .001" feeler gauge. Clearance should be at .001" to .0015". Adjust clearance by repeating steps 1-5 with different shim if necessary.
7. Once proper rotor/gap clearance is achieved, install well lubricated **01011** Blades (4) into rotor slots. Dynabrade air lube P/N **95842** is recommended for lubrication.
8. Install cylinder over rotor. Be sure air inlet holes of cylinder face away from front bearing plate.
9. Press **01015** Rear Bearing into **01244** Rear Bearing Plate. Press bearing/bearing plate assembly onto rotor. Be sure that pin and air inlet holes line-up with pin slot and air inlet holes in cylinder.
Important: Fit must be snug between bearing plates and cylinder. If too tight, rotor will not turn freely. Rotor must then be lightly tapped at press fit end so it will turn freely while still maintaining a snug fit. A loose fit will not achieve the proper preload of motor bearings.
10. Secure motor housing in padded vise so motor cavity faces upwards.
11. Install motor assembly into housing, making sure motor drops all the way into housing.
Note: Align the rear bearing plate node with the notch inside the housing.
12. Insert air control ring and **04078** Felt Silencer into **04102** Lock Ring and install onto motor housing (torque 34 N•m/300 in. - lbs.).
13. Motor adjustment can now be checked. With motor housing still mounted in vise, pull end of rotor and twist (10-15 lbs. force), rotor should turn freely without drag. If drag or rub is felt, then increase preload or remove shim. Also, push end of rotor and twist (10-15 lbs. force), rotor should turn freely without drag. If drag or rub is felt, then deload or add shim.

Valve Body Assembly:

1. Insert **01247** Speed Regulator Assembly with o-rings into valve body. Secure with **95558** Retaining Ring.
2. Secure valve body in vise with air inlet pointing up.
3. Insert **01464** Seal into housing.
4. Line up hole in valve stem with hole in housing (looking past brass bushing). Insert **01472** Tip Valve so that the metal pin passes through the hole in the valve stem. Install **01468** Spring (small end towards tip valve).
5. Install **96065** O-Ring onto **53190** Block Plate.
6. Install **53190** Block Plate into housing.
7. Apply Loctite® #567 PST Pipe Sealant to threads of **01494** Inlet Adapter and install onto valve body (torque 23 N•m/200 in. - lbs.).
8. Install **57342** Throttle Lever and **01017** Pin.

Tool Assembly Complete. Please allow 30 minutes for adhesives to cure before operating tool.

Important: Motor should now be tested for proper operation at 90 PSIG. If motor does not operate properly or operates at a higher RPM than marked on the tool, the tool should be serviced to correct the cause before use. Before operating, place 2-3 drops of Dynabrade Air Lube (P/N **95842**) directly into air inlet with throttle lever depressed. Operate tool for 30 seconds to determine if tool is operating properly and to allow lubricating oils to properly penetrate motor

Loctite® is a registered trademark of Loctite Corp.

Optional Accessories



Dynaswivel®

Swivels 360° at two locations which allows an air hose to drop straight to the floor, no matter how the tool is held.

- 94300 1/4" NPT



95600 Motor Tune-Up Kit:

- Includes assorted parts to help maintain and repair motor.



Dynabrade Air Lube

- Formulated for pneumatic equipment.
- Absorbs up to 10% of its weight in water.
- Prevents rust and formation of sludge.
- Keeps pneumatic tools operating longer with greater power and less down time.

95842: 1pt. (473 m)

95843: 1gal. (3.8L)

Wrenches



50971 Lock Ring Tool

- Lock ring tool has a 3/8" square socket for use with 3/8" drive; breaker bar, ratchet head, or torque wrenches.

Visit our web Site: www.dynabrade.com

Email: Customer.Service@Dynabrade.com



DYNABRADE, INC., 8989 Sheridan Drive • Clarence, NY 14031-1490 • Phone: (716) 631-0100 • Fax: 716-631-2073 • International Fax: 716-631-2524
DYNABRADE EUROPE S.à.r.l., Zone Artisanale • L-5485 Wormeldange—Haut, Luxembourg • Telephone: 352 76 84 94 1 • Fax: 352 76 84 95 1

© DYNABRADE, INC., 2001

PRINTED IN USA