



- 1) Drill or knock out two (2) rivets as shown ●
- 2) Lay flat side of metal clip with DEE on outside of bag lining up holes.
- 3) Insert male half of slam rivet through holes and lay bag on hard surface.
- 4) Install female half of slam rivet and hit with hammer to tighten.