






Slim Jim® Recycling Station Assembly Guide


Parts Included:




Bases




Billboards*




Connectors



Lid inserts*




Lids




Labels x10*

*Billboards, Lid Inserts, and Labels not included with 23G and 33G Slim Jim Recycling Station Starter Kits (2007913 and 2171553)




Align Base to Connector

1. Align connector underneath base rim, matching tabs to respective holes.



Attach Connector to Base

2. Slide connector upward until tabs click into place.




Connect Additional Base

3. Lift second base on top of connector, pressing down on base to snap tabs into place.




Slim Jim® Recycling Station Assembly Guide (continued)




Apply Labels to Billboards

4. Remove backing from label. Align the bottom edge of the label with the raised line on the billboard. Place label and smooth upward within the recessed area on billboard.




Connect Billboards to Bases

5. Insert the tab on bottom of billboard into base handle until it clicks into place.



Connect Lid Insert to Lids

6. Turn lid and lid insert upside down.
7. Feed the lid insert through the lid opening so that the lid insert's tab is on the outside of the lid.
8. Ensure the lid insert's pegs snap into the lid's corresponding peg holes. After inserting one peg, pull the gray tab to the side on the other peg for an easier connection.



Attach Lids to Base

9. Place lids on top of the bases.